

Installation guide



Thermostatic expansion valves

Type TU and TC


068R9543



068R9543




TUE / TCE




Danfoss
68U302.10

TUE / TCE




Danfoss
68U303.10

TU / TC




Danfoss
68U304.10



1






2



3






TU/TCMOP: $t_2 > t_1$
Superheat SH = $t_1 - t_s$


Factory setting
Static superheat:

N, B: 4 °C (7 °F)
NMOP, NM: 4 °C (7 °F)
BMOP: 4 °C (7 °F)




TU

R22 R407C	R134a R513A	R404A R507 R410A	ΔSS 1 ×
	N		2 °C (3.6 °F)
N	NM	N,B	2.5 °C (4.5 °F)
NM,B		NM	3 °C (5.4 °F)



TC

R22 R407C	R134a R513A	R404A R507	R410A	ΔSS 1 ×
	N			1 °C (1.8 °F)
N	NM	N,B	N,B	1.5 °C (2.7 °F)
NM,B		NM	NM	2 °C (3.6 °F)



Temperature ranges:

N = -40 - 10 °C / -40 - 60 °F
NM = -40 - -5 °C / -40 - 25 °F
B = -60 - -25 °C / -75 - -15 °F